

Installation instructions

Pretec Elevator Chain link 40kN

It is important that the bent threaded rod is fixed in a standing position when concrete is poured.

The chain link can be rotated around its center to fix the threaded to nearby reinforcement.

It is not allowed to cut the threaded rod.

Regular execution is with stirrups mounted next to the chain link box (40kN). Contact responsible structural designer/engineer if the stirrups are not present on the concrete element drawing. Under some circumstances for 20kN they can be excluded, if verified by designer/engineer.

